SITE WEATHER · HOIMA · FRIDAY 20 NOVEMBER

Storms possible from 14:00: do exposed work in the morning.

Rain 1 mm · 75% | Storms possible from 14:00 | Heat 28 °C WBGT | Gusts 7 m/s

CONCRETE POUR

Limited **Go 08-12 h**

08	09	10	11	12	14	15	16

Limited by rain, storms. Keep covers ready outside this window.

ASPHALT & SURFACING

Limited **Go 08-11 h**

08	09	10	11	12	14	15	16

Limited by rain or wet surface, storms. Never lay or spray on a wet surface.

CRANE LIFTS

Limited **Go 08-13 h**

08	09	10	11	12	14	15	16

Limited by storms. Check the anemometer before each lift.

WORK AT HEIGHT

Limited **Go 08-12 h**

08	09	10	11	12	14	15	16

Limited by storms, rain. Clear roofs and scaffolds before storms.

PAINTING & COATINGS

Limited **Go 10-12 h**

08	09	10	11	12	14	15	16

Limited by rain, humidity or dew. Check the surface is 3 °C above dew point.

EARTHWORKS

Limited **Go 08-12 h, 14-16 h**

08	09	10	11	12	14	15	16

Limited by rain. Protect formation and stockpiles.

Go NO WEATHER LIMITS

Outdoor labour.

Screening guidance from a forecast. Your contract, crane limits and site H&S plan come first.

gavacharles.github.io/kampala-heat-atlas/site-weather/hoima

By Gava Charles · Kampala Heat Atlas · forecast data Open-Meteo

SITE WEATHER · HOIMA

The week on site

When each trade can go ahead, 08-17 h, lunch excluded

	Fri 20	Sat 21	Sun 22	Mon 23	Tue 24	Wed 25	Thu 26
Outdoor labour	all day	all day	all day	all day	all day	all day	08-13 14-15+
Concrete pour	08-12	08-12	08-10	08-10	none	08-12	08-10
Asphalt & surfacing	08-11	09-12	08-10	08-09	none	08-12	08-10
Crane lifts	08-13	08-13	08-12	08-12	08-11	08-09 10-13	08-12
Work at height	08-12	08-13	08-10 11-12	08-09	08-11	08-09 10-13	08-10
Painting & coatings	10-12	11-13	none	none	none	12-13	none
Earthworks	08-12 14-16	all day	08-10 11-13+	08-10	none	08-13 14-16	all day
Rain	1 mm 75%	0 mm 59%	3 mm 82%	12 mm 92%	7 mm 98%	2 mm 93%	2 mm 82%
Storms	possible	possible	possible	likely	likely	possible	possible

go most of the day · part of the day · little or none

Times are go windows: 08-13 = from 08:00 until the lunch break; + = more windows that day.

Screening guidance from a forecast. Your contract, crane limits and site H&S plan come first.

gavacharles.github.io/kampala-heat-atlas/site-weather/hoima

By Gava Charles · Kampala Heat Atlas · forecast data Open-Meteo

SITE WEATHER · HOW IT WORKS

How to read the cards

A daily weather check for contractors and site managers

STEP 01 · 1

The headline

The one thing to plan the day around. The key time is marked in yellow.

STEP 02 · 2

A card per trade

Problems first: Stop, Limited (go only in the hours shown), Care. Trades with no limits share one card.

STEP 03 · 3

Hour chips

8 working hours, 08:00-17:00, lunch excluded. Green go, amber care, red stop.

STEP 04 · 4

Heat uses WBGT

The standard for heat stress at work; it sets work/rest cycles.

STEP 05 · 5

Concrete and asphalt

Rain now or within three hours, wet surfaces, and drying fast enough to crack fresh concrete (ACI 305).

STEP 06 · 6

Cranes and painting

Gusts at 30 m hook height and storms; painting needs the surface 3 °C above dew point (ISO 8502-4).

STEP 07 · 7

Every day on record

Month by month against the 1991-2020 climate, for programme reviews and delay claims.

Screening guidance from a forecast. Your contract, crane limits and site H&S plan come first.

gavacharles.github.io/kampala-heat-atlas/site-weather/hoima

By Gava Charles · Kampala Heat Atlas · forecast data Open-Meteo